











\*\* The Remote control has been pre-set up and completed the learning/setting. <u>In the event of no operation, do the following to reset the remote:</u> Switch off the main power and wait for 10 seconds, then switch on the power again and immediately do the setting below.













